


# How to send AT commands by SMS

1. First, open setting software, view the command password



2. SMS format

**usr.cn#AT+command**

For example: usr.cn#AT+VER

usr.cn#AT+APN



3. The AT commands :

[https://www.usriot.com/download/GPRS/USR-GM3-AT-Command-Set\\_V1.0.2.pdf](https://www.usriot.com/download/GPRS/USR-GM3-AT-Command-Set_V1.0.2.pdf)